

LINEAR SERVO DRIVE LINEAR Σ SERIES INSTRUCTIONS

For Magnetic Way

NOTES FOR SAFE OPERATION

Upon receipt of the product and prior to installing the product, read these instructions thoroughly, and retain for future reference.

WARNING

- Any person having electronic medical devices such as a pacemaker must not approach the magnetic way.
Failure to observe this warning may result in incorrect operation of the electronic medical device.

CAUTION

- Pay attention to the magnetic attraction when unpacking the magnetic way.
Failure to observe this caution may result in injury or damage to the magnetic way.
- Do not place any magnetic objects such as iron particles close to the magnetic way.
Failure to observe this caution may result in injury.
- Do not place any electronic devices such as clocks, magnetic cards, floppy disks, or measuring devices close to the magnetic way.
Failure to observe this caution may result in incorrect operation or mechanical failure of the electronic devices.
- Pay attention to the magnetic attraction and confirm that there are not any magnetic objects such as iron particles attached before mounting the magnetic way.
Failure to observe this caution may result in injury or damage to the magnetic way.
- When handling the magnetic way with the magnet protection cover, do not grab the cover.
Failure to observe this caution may result in injury caused by the end of the cover or deformation of the cover.
- When removing the dummy plate for reducing magnetic force used for the SGLFM magnetic way, pay attention to the magnetic attraction of the magnetic way. Do not place the removed plate close to the magnetic way.
Failure to observe this caution may result in injury or damage to the magnetic way's magnets or the magnet protection cover.



YASKAWA

MANUAL NO. TOB-C238-1B

© 2000-2005 YASKAWA ELECTRIC CORPORATION. All rights reserved.
Printed in Japan July 2005 00-9 